

NOTE: Installation Guide is generalized for **solid masonry** installations and is intended to help plan for a simple & easy install & product usage. Personal & specific structural physicalities may require deviation from this guide, always consult with a hardware or contractor professional.



M10 Expansion Bolt
for masonry installations

Sold Separately
Part# ZDA-WEB-R2

Installation.

Follow Owners Manual Step 1 and Step 2 for Marking & Pre-Drilling. Continuing here with Step 3 through end.

- With a 3/8" x 4" masonry drill bit, drill top hole between 2 1/4" to 2 1/2" deep and between 2 3/4" to 3" deep for bottom hole.

Remove any excess dust and debris from holes with a tube brush or vacuum.





- Align and place the door awning brackets (assembled awning) over the pre-drilled holes.

Insert the complete expansion bolt through the bracket until flush.

TIP: A mallet may be needed to tap the expansion bolt into the wall.

CAUTION! IMPORTANT!

Awning **MUST** be mounted to main structural supports, header, or solid masonry 3-inch in thickness or more. For brick walls, avoid grout lines.



- 5 With a 1/2" socket wrench, tighten the the bolt head.
The wedge bolt should begin to tighten within the sleeve with every turn securing the bolt sleeve and wedge into the wall.

CAUTION: Do not overtighten, doing so may damage the bracket.

Repeat for all brackets.

